

McHale User Guide

BACK [MATERIAL]

Elastomeric mesh webbing

LUMBAR SUSPENSION SYSTEM + SEATBACK HEIGHT

Pull up the seatback, the chair back will ratchet click into higher notch positions, until it reaches the top position, at which point you can slide it back to the lowest setting. Turn the knob to dial in an increase or decrease in the degree of curve in the mesh back.

SEAT HEIGHT ADJUSTMENT

For desired seat height use the lever under the right side of the seat. To raise the seat, lift the lever up while taking your weight off the chair. To lower the seat, stay seated and lift the lever. Release the lever when you reach the desired height.

SEATBACK TILT TENSION

Pull the knob out first. To increase seatback tension, turn the tension knob clockwise to tighten and counterclockwise to loosen. Push knob back into position when adjustment complete.

4D ARMRESTS

To adjust the height, press the trigger at the front of the arm, adjust to desired height and release. Arm caps slide forward and back for forearm support. A soft inward press of the arm will tip them close to the body for optimal support when using a keyboard. Slide outwards (or inward) to accommodate your forearms when mousing.

SEATBACK ERGO TILT AND LOCK

To lock the recline of the backrest, lean back to the desired position, twist the tilt lock knob clockwise to lock in place. To release, twist the knob counter clockwise to unlock.

CASTERS

Standard black carpet casters, or optional black dual surface casters.

HEIGHT ADJUSTMENT

TILT TENSION

TILT LOCK LEVER

