


USER INSTRUCTIONS

HEIGHT ADJUSTMENT

STEP 1


ZIPLIFT+ 35"

Press and hold the levers.




ZIPLIFT+ 42" HD

Press and hold lever on right side.




STEP 2

With two hands, lift up and out.*



With two hands, lift up and out.*




KEYBOARD TRAY ADJUSTMENT


STEP 1

STEP 2

Twist to loosen knob.

Lift tray to desired angle and tighten knob.






WEIGHT CAPACITY

ZIPLIFT+ 35"

A ≤ 35 lbs B ≤ 5 lbs

A. The ZipLift+ 35" holds up to 35 lbs. total. B. The keyboard tray itself holds up to 5 lbs.

ZIPLIFT+ 42" HD



A. The ZipLift+ HD 42" holds up to 45 lbs. total. B. The keyboard tray itself holds up to 5 lbs.